

# HM2000 Decono® Shower Instruction Sheet

- A** Remove, inspect and count all parts (see parts list below).
- B** Assemble base by connecting the two Shower Support Legs (1) to the Upright Valve Coupling (2).
- C** Insert Vertical Upright (3) into Upright Valve Coupling (2) as shown.
- D** Insert Shower Head Attachment (4) into Vertical Upright (3) as shown.
- E** Attach water hose (garden hose fitting) to Shutoff Valve at base of shower.

***You're Done!!***

***For Storage:***

After use, clean and let fully dry before storage.

***Caution:***

Regulate water temperature to avoid scalding.

**HM2000 Decono® Parts List**

Description	Qty.
#1 Shower Support Legs	2
#2 Upright Valve Coupling	1
#3 Vertical Upright	1
#4 Shower Head Attachment	1

